


CLUTCH (1970-1984)



1. Pushrod adjusting screw locknut
2. Adjusting screw
3. Spring tension adjusting nut (3)
4. Spring collar
5. Springs (10)
6. Outer disc (pressure plate)
7. Steel disc (4)
8. Friction disc (5)
9. Clutch shell
10. Clutch hub nut (left hand thd.)
11. Hub nut lockwasher
12. Clutch hub
13. Clutch hub key
14. Bearing plate spring (3)
15. Bearing plate
16. Bearing retainer
17. Bearing roller
18. Hub nut seal

